

**TANDEM full extension with BLUMOTION – 560H** Web code  
DQD1XA

**Planning**

Space requirement in cabinet	Drawer   inner drawer	Drawer	Inner drawer
<p>* +3 mm with side stabilisation</p>	<p>SKW Internal drawer width LW Internal cabinet width</p>	<p>SKL Drawer length NL Nominal length * Additional +12 mm with side stabilisation</p>	<p>ISKL Inner drawer length SKL Drawer length NL Nominal length X Front thickness * Additional +2 mm with POSISTOP</p>

**Hole spacing – runners**

Runner – 560H – 30 kg  
Nominal length NL (mm)

250   270	
300   320   350   380	
400   420	
450   480	
500   520   550	
600	

**Drawer assembly**

Use drilling template T65.1000.02	Use drilling template T65.1000.02

**Reference pages**

Overview	447	Assembly, removal and adjustment
SERVO-DRIVE for MOVENTO   TANDEM	492	
CABLOXX	582	
Accessories	482	Short URL
Attachment of runners	490	<a href="http://www.blum.com/a420">www.blum.com/a420</a>
E-SERVICES and assembly devices	590	
More technical details	698	

